


GB

REGULATOR WATCH

Art. No. 23423

INSTRUCTION MANUAL



PLEASE NOTE:

Please note that the battery stopper (avoids drainage of battery when disused) must be removed and the crown must be pushed back to position 1 after time setting.

TIME READING:

This watch shows hours, minutes and seconds in separate displays.

How to read the hour: The anti-clockwise arranged Roman numbers on the large-scale display show the hours. The hour hand hence moves anti-clockwise to show the time.

How to read the minutes: The large-scale Arabic numbers in the fan shaped window show the minutes. The minute hand however is immobile. Only the minute disc will move clock-wise in order to show the correct time.

How to read the seconds: The small-shaped Arabic numbers on the small-scale round display show the seconds. The seconds hand moves

clock-wise in order to show the accurate time.

TIME SETTING:

Pull out crown to position 2 and rotate the crown clock-wise until the correct time is set. When correct time is set, push back the crown to position 1 to start the time.

REMARK:

- Please always rotate the crown to set the time in clock-wise direction.
- Battery type: SR626SW.

DISPOSAL:

The packaging material is reusable. Dispose of the packaging in an environmentally friendly way by putting it in the appropriate recyclable waste collection containers.



Dispose of the product and the batteries in view of the environment if you want to separate. The device and the batteries must not be thrown in with domestic waste. Take them to a recycling center for used electrical and electronic devices. For more information you can consult your local government. Remove batteries first.

Eurotops Versand GmbH
Elisabeth-Selbert-Straße 3
40764 Langenfeld, Germany



If technical support is needed, please call ...

in Germany 0180 . 530 63 63* or info@eurotops.de

in Austria 01 . 230 60 43 12 or info@eurotops.at

in Switzerland 044 . 28 36 125 or info@eurotops.ch

in the Netherlands 026 . 37 36 333 or info@eurotops.nl

in France 0892 . 700 470** or info@eurotops.fr

* 14 Cents/minute via German landline, max. 42 cents/minute via mobile phone network

**34 Cents/minute via French landline

A possible return of products should be addressed to the return address stated on your

invoice.

The manual only reflects the technical conditions available under printing.

Any changes in technology and equipment are reserved.

© 26.11. 2013