


PICK-UP TOOL WITH FLEXIBLE SHAFT

Art. No.: 25715

INSTRUCTION MANUAL



- 1) Press and hold the cylinder head (① above) to adjust the claw to lift up to around 0.45 kg non-metallic items
- 2) Push button to switch on/off LED (② above)
- 3) Magnetic pick up head on the top to lift up to around 0.45 kg metallic items
- 4) Batteries: 3 X LR444 (included), please refer to ③ to change battery in the correct polarity direction



DISPOSAL:

The packaging material is reusable. Dispose of the packaging in an environmentally friendly way by putting it in the appropriate recyclable waste collection

containers.



Dispose of the product and the batteries in view of the environment if you want to separate. The device and the batteries must not be thrown in with domestic waste. Take them to a recycling center for used electrical and electronic devices. For more information you can consult your local government. Remove batteries first.

Eurotops Versand GmbH
Elisabeth-Selbert-Straße 3
40764 Langenfeld, Germany



If technical support is needed, please call ...

in Germany 0180 . 530 63 63* or info@eurotops.de

in Austria 01 . 230 60 43 12 or info@eurotops.at

in Switzerland 044 . 28 36 125 or info@eurotops.ch

in the Netherlands 026 . 37 36 333 or info@eurotops.nl

in France 0892 . 700 470** or info@eurotops.fr

* 14 Cents/minute via German landline, max. 42 cents/minute via mobile phone network

**34 Cents/minute via French landline

A possible return of products should be addressed to the return address stated on your invoice.

The manual only reflects the technical conditions available under printing. Any changes in technology and equipment are reserved.

© 18.12.2014