



USER MANUAL





TABLE OF CONTENTS



Box content	03
Buttons	04
How to use	05
How to clean	11
Warnings	12
Support	15
Storage	16
Warranty	17
Legal	18

BOX CONTENT



1. Handy™


2. TrueGrip™ band

3. TrueGrip™ sleeve

4. Power supply

5. Power cable

BUTTONS




1. Power on/off
2. Increase stroke length
3. Decrease stroke length
4. Increase speed
5. Decrease speed
6. Wi-Fi button
7. Indicator LED

HOW TO USE




STEP1. CONNECT THE POWER SUPPLY TO THE WALL SOCKET.



HOW TO USE



STEP2. CONNECT TO HANDY™





HOW TO USE



STEP3.

Insert your penis as far as possible into the sleeve.




HOW TO USE



STEP4.

Place the sleeve into the TrueGrip™ band.



NOTE: the buttons should be facing you.

HOW TO USE



STEP5.

Adjust the TrueGrip™ band according to your preferred grip. It should be tight enough to securely hold the sleeve in place.




HOW TO USE



STEP6.

Turn Handy™ on by pressing the Power On button. Adjust the speed and stroke with the corresponding buttons.



NOTE!

Always hold the top of Handy™ firmly and keep fingers away from moving parts!

Warning!


Always be prepared to switch off the power

HOW TO CLEAN




Warning!

Keep your Handy™ away from water!
Use a damp cloth on Handy's exterior
surface to keep it clean





- Clean your sleeve directly after use.
- Use soap and warm water when you clean the sleeve.
- You can turn the sleeve inside out for a deeper clean.
- Dry with a towel.

WARNINGS




Do not use near or in water. This is an electrical appliance. Electric shock may result in injury or death.

WARNINGS




Only use Handy™ with the sleeve installed.
Do not use Handy™ without the sleeve as
an injury may result.

WARNINGS



Handy™ is a powerful tool, with high speed and torque. Faulty usage may result in injuries. You use Handy™ at your own risk. If you do not accept, please return Handy™ for a refund. Conditions apply. See theHandy.com for all conditions.



For support and to read the full
manual visit
www.handysetup.com

STORAGE



Store your sleeve in a sealed plastic bag to extend its life and to keep the texture.

Store Handy™ in a dry and cool place, preferably in the product box.

Keep Handy™ away from sunlight.

WARRANTY



Unless stated otherwise, Handy™ warrants the motor, gear and electronics are covered for a period of one (1) year. The warranty period starts from the day of purchase. The warranty covers defects due to manufacturing errors or faulty parts. Handy™ is not covered by the warranty if it is opened or tampered with. The warranty does not cover the sleeve or the trueGrip™ band. Normal wear and tear, like cosmetic deterioration, are not covered. Warranty void if damages are caused by misuse, neglect, or accident.

Handy™ is a registered trademark of Sweet Tech AS.
Handy™ is U.S. patent pending.
Handy™ is a novelty only and has no therapeutic or medical application.

For more info, contact us at
contact@thehandy.com

Sweet Tech AS 2019 All Rights Reserved.



handyTM